

# **Flight Instruments and Avionics**

## **Objective**

To understand the basic flight instruments used for flight, their limitations and biases, plus common failure modes.

## **Motivation**


To give a student an intuitive understanding of the operation of the flight instruments, and a sense of how they will behave if they malfunction.

# Overview

- Pitot-Static instruments
  - Altimeter
  - Vertical Speed Indicator
  - Vertical Speed Indicator
  - Airspeed indicator
- Pitot-static port blockages
- Inclinator
- Gyroscopic and vacuum Instruments
  - Attitude Indicator
  - Directional Gyro/Heading Indicator
  - Horizontal Situation Indicator (HSI)
- AHRS and EFIS Systems
- Vacuum System Failures
- Magnetic Compass
  - Compass errors








## Pitot-Static instruments


- Static port: Ambient air pressure
- Pitot tube: Ram air pressure, in the relative wind flow



## Altimeter

- Converts barometric pressure into altitude
- Calibrated to the lapse rate of the standard atmosphere ( $2^{\circ}$  per 1000', 1" Hg per 1000')
- Calibrated to the temperature of the standard atmosphere ( $15^{\circ}$  @ S.L.)
- Kollsman window allows for calibrating the atmosphere indicator up and down
  - Window does have a set range


# Nonstandard Temperature Errors



- Colder temperatures: "Compress" the column of air below, altimeter reads higher
- Hotter temperature: "Expand" the column of air below, altimeter reads lower

# Types of Altitude


- **Indicated** altitude: Read from the altimeter
- **True** altitude: Vertical distance from mean sea level
- **Absolute** altitude: Vertical distance above terrain (AGL)
- **Pressure** altitude: Read from altimeter when set to 29.92"
  - Height in the standard atmosphere where the ambient pressure is found
- **Density** altitude: Pressure altitude corrected for nonstandard temperature



## Vertical Speed Indicator


- Rate of change of the altitude/ambient pressure
- Will lag considerable with pressure alone





## Instantaneous Vertical Speed Indicator (IVSI)

- Accelerometer weights help lead the indication before pressure changes



## Airspeed indicator

- $\text{Airspeed} = (\text{Ram air pressure} - \text{static pressure})$
- Operates with a diaphragm

# Types of Airspeed

- Indicated airspeed (IAS): Read from altimeter
- Calibrated airspeed (CAS): Calibrated for position/instrument errors
  - At slow airspeeds this may be several knots off
- True airspeed (TAS): CAS corrected for altitude and nonstandard temperature
- Ground speed (GS): Actual speed over the ground
  - TAS adjusted for wind


# IAS vs CAS

## CONDITIONS:

Power required for level flight or maximum power descent.


|            |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
|------------|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|--|
| FLAPS UP   |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| KIAS       | 50 | 60 | 70 | 80 | 90 | 100 | 110 | 120 | 130 | 140 | 150 | 160 | 170 |  |
| KCAS       | 61 | 65 | 72 | 80 | 89 | 99  | 109 | 118 | 128 | 138 | 147 | 157 | 167 |  |
| FLAPS 20°  |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| KIAS       | 40 | 50 | 60 | 70 | 80 | 90  | 95  | --- | --- | --- | --- | --- | --- |  |
| KCAS       | 54 | 58 | 63 | 71 | 80 | 89  | 94  | --- | --- | --- | --- | --- | --- |  |
| FLAPS FULL |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| KIAS       | 40 | 50 | 60 | 70 | 80 | 90  | 95  | --- | --- | --- | --- | --- | --- |  |
| KCAS       | 52 | 57 | 63 | 71 | 80 | 90  | 95  | --- | --- | --- | --- | --- | --- |  |

Figure 5-1. Airspeed Calibration (Sheet 1 of 2)



## Airspeed Indicator Markings

- $V_{S0}$ : Stall speed in landing configuration
- $V_{S1}$ : Stall speed in clean configuration
- $V_{FE}$ : Flap extension speed (full flaps)
- $V_{NO}$ : Maximum structural cruising speed (smooth air only)
- $V_{NE}$ : Never exceed speed
- Note  $V_A$  is not marked




## Pitot Blockages


- Ram air block: Airspeed reads 0
- Ram air + drain hole blocked:
  - Airspeed reads whatever it was when it was blocked
  - If you descend it'll read lower, higher if ascending



# Static Port Blockages



- Most airplanes have an alternate static source
  - This will vent into the cockpit, which may have slightly lower pressure
- VSI will show no climb or descent
- A blocked static port will cause errors in the airspeed indicator
  - Recall  $\text{Airspeed} = \text{RAM pressure} - \text{static pressure}$
  - Airspeed is accurate at altitude where blockage occurred
  - Above the altitude, airspeed reads low
  - Below the altitude, airspeed reads high




## Gyroscopic Instruments

- Operate on the principle of gyroscopic stability
- Corollary: Bicycle wheel stability at low vs high speeds
- Mechanical flight instruments use a spinning rotor
  - Vacuum pump (engine-driven or electric)
  - Pressure
  - Electrical motor
- Aircraft rotates around the gyro




# Vacuum Instruments



- In a standard "six pack":
  - Vacuum-driven gyroscopic system drive the attitude and heading indicators
  - Sometimes the turn coordinator

# Turn Coordinator



- 1-axis gyro
- Indicates rate of yaw/turn rate around the vertical axis
- No primary bank information



Slipping turn




Skidding turn



Coordinated turn

## Inclinometer

- Indicates coordination of flight
- Not gyro or electrically operated
- Ball with mass in a fluid, like a level




## Attitude indicator

- Indicates rotational position of the longitudinal (pitch) and lateral axis (roll)
- Adjustment knob to set horizon to level
- Pitch limit usually around 100-110°
- Bank limit around 60-70°

## Directional Gyro/Heading Indicator

- Indicates rotational position about the vertical axis
- Must be continually calibrated with the magnetic compass
  - Earth rotates in space at a rate of  $15^\circ$  in 1 hour
  - Gyroscopic precession: gimbal is not frictionless, small forces cause position drift







## Horizontal Situation Indicator (HSI)

- Often overlay VOR CDI needles
- Some can be "slaved" to a magnetic sensing device
  - Eliminates the need to manually calibrate with the magnetic compass




## Attitude and Heading Reference System (AHRS)

- No moving parts
- Uses accelerometers for roll/pitch/yaw information
- Use a magnetometer for heading information, often mounted on the wing
- Feeds modern glass-panel displays
- Less susceptible to mechanical failures

# Vacuum System Failures




- A loss of vacuum pressure will result in a slow spin-down of gyros
- An attitude indicator will show a slow lean/dive
- Utilize a cross-checking scan





# Magnetic Compass

- Self-contained, no power needed
- Operates on the magnetic pull of the Earth







# Compass Errors and Variation

- Magnetic variation: Magnetic north vs true north
- Magnetic deviation: Magnetic fields from electrical equipment in an aircraft can cause errors
- Magnetic dip errors: North and south turning errors
- Acceleration errors: Accelerating on an east/west heading




# Magnetic Variation



- True North and Magnetic north are not in the same spot
- The difference between true and magnetic is called variation
- This varies depending on your location on Earth


# Isogonic Lines - Tells us Magnetic Variation



## Magnetic Deviation

|       |                |      |      |      |      |      |
|-------|----------------|------|------|------|------|------|
| For   | N              | 030  | 060  | E    | 120  | 150  |
| Steer | 005°           | 027° | 063° | 090° | 122° | 147° |
| For   | S              | 210  | 240  | W    | 300  | 330  |
| Steer | 176°           | 207° | 237° | 270° | 308° | 339° |
| Date  | April 18, 2013 |      |      |      |      |      |

- The magnetic field for various electronic/magnetic/metallic components in the airplane can skew the direction of the compass
- The compass correction card gives you calibration to account for this
- Compass correction cards are specific to each airplane




## Magnetic Dip

- As you get closer to the poles the vertical component of the magnetic field get stronger (and the horizontal component gets weaker)
- Compasses can compensate for this when they are level
- When they are tilted though, the results may be skew




# Magnetic Dip Errors

- When turning through a N or S heading
- North: compass card leads actual heading
- South: compass card lags actual heading
- "UNOS"
  - Undershoot North
  - Overshoot South



# Acceleration Errors

- Compass card is not a uniform mass
  - It's a little heavier on the north side, to account for dip
- "ANDS"
  - Accelerate: North
  - Decelerate: South



## Getting an Accurate Compass Reading

- Straight and level, unaccelerated flight
- Account for deviation using the compass correction card
- Know when to use true headings vs magnetic headings
- Magnetometer-based (electronic flight displays) systems won't have these errors



# Summary

- Pitot-Static instruments
  - Altimeter
  - Vertical Speed Indicator
  - Vertical Speed Indicator
  - Airspeed indicator
- Pitot-static port blockages
- Inclinator
- Gyroscopic and vacuum Instruments
  - Attitude Indicator
  - Directional Gyro/Heading Indicator
  - Horizontal Situation Indicator (HSI)
- AHRS and EFIS Systems
- Vacuum System Failures
- Magnetic Compass
  - Compass errors



## Knowledge Check

If you were to lose electrical power to the avionics bus in your airplane, which instruments would stop working?

## Knowledge Check

Flying in an airplane with a vacuum system, you notice that your heading indicator is starting to drift and the attitude indicator is leaning to the left. What might this indicate?

## Knowledge Check

You're turning to a heading a 360° N using the magnetic compass. How would you ensure you roll out right on your heading?